daylog eld

If the ELD stops working

Malfunction and data diagnostic guide · Daylog ELD

Must stay in the vehicle and be available during inspections — 49 CFR § 395.22(h).

Signs of a malfunction

- A red “ELD” badge or a malfunction banner in the app.
- The device is missing from Me › ELD device.
- Duty status or location stops updating.

What the driver does

1. Note the malfunction and tell your carrier within 24 hours.
2. Rebuild today and the previous 7 days on paper duty-status graphs, unless those records are still available in the app.
3. Keep logging on paper until the ELD is repaired or replaced.

What the carrier does

1. Repair or replace the ELD within 8 days of learning about the malfunction (§ 395.34).
2. Keep the driver’s paper records for at least 6 months.

P	E	T	L	R	S	O
Power	Engine sync	Timing	Positioning	Data recording	Data transfer	Other